



FIGURE-Index N° PART N° DESCRIPTION
remarks

Models affected.

NOSE GEAR & SUPPORT FRAME

All models

200	- 0	42 26 00 000	Nose gear, equipped (without wheel)	
	- 1	42 26 01 100	Fixed leg, nose gear	
	- 2	42 26 12 100	Sliding leg, nose gear.....	
	- 3	41 12 03 030	Inflating valve.....	
	- 4	41 12 03 030	Valve cap.....	
	- 5	41 21 04 000	Retaining ring, internal.....	
	- 6	42 20 32 010	Bush bearing, lower (equipped with o-ring part 42 23 03 010)	
		41 18 11 010	Bush bearing, lower (equipped with <u>Quad-Ring</u> part 41 18 11 020).....	all, from S/N 1900 (?)
	- 7	42 23 03 000	O ring (static).....	
	- 8	42 23 03 010	O ring (dynamic)	
		41 18 11 020	Quad Ring seal (used with part 41 18 11 010 bush bearing)	all, from S/N 1900 (?)
	- 9	42 23 09 010	Scraper ring.....	
	- 10	40 23 04 000	Retaining ring	
	- 11	42 23 07 500	Stop ring, lower	
	- 12	42 23 05 000	Diaphragm.....	
	- 13	42 23 06 500	Stop ring, upper	
	- 14	41 23 59 005	Torque link half.....	
	- 15	42 23 06 000	Bush (plastic).....	
	- 16	42 23 08 000	Bush (plastic).....	
	- 17a	41 20 47 000	Bolt.....	
	- 17b	41 20 48 010	Shaft.....	
	- 18	42 23 08 500	Washer	
	- 19	42 23 07 000	Washer, plastic	
	- 20	95 22 04 000	Nut.....	
	- 21	42 26 02 000	Rod, locking control	
	- 22	95 21 06 000	Nut.....	
	- 23	42 34 12 020	Guide, control rod	
	- 24	42 34 11 000	Locking pawl, with roller.....	
	- 25	95 13 38 000	Screw	
	- 26	95 24 02 000	Nut , self-locking	
	- 27	42 34 11 040	Screw	
	- 28	42 11 04 000	Grease nipple.....	
	- 29	95 14 24 000	Screw, taper lock.....	
	- 30	-----	(suppressed item).....	
	- 31	42 34 42 030	Bracket, wheel spat supporting (aluminium casting); supersedes 31b.....	
	- 31b	without	Bracket, wheel spat supporting (superseded).....	NP
	- 32	95 12 06 010	Screw	
	- 33	95 61 04 000	Washer	
	- 34	95 24 04 000	Nut , self-locking	
	- 35	42 12 02 000	Frame, front L/G supporting, equipped with (35b) bushings.....	
	- 35b	42 34 03 030	Bushing, (upper or lower.)	Superseded assembly
	- 36	42 26 03 000	Shaft, front L/G pivot	See Fig 201 for
	- 37	41 21 05 000	Spring washer (anti-shimmy device).....	replacement shaft
	- 38	43 23 02 000	Nut.....	
	- 39	95 13 41 000	Screw	
	- 40	95 24 02 000	Nut , self-locking	
	- 41	42 21 03 000	Cam plate, centering	
	- 42	95 13 01 010	Screw	
	- 43	95 61 04 000	Washer	
	- 44	95 24 04 000	Nut, self-locking.....	
	- 45	95 13 16 000	Screw	
	- 46	95 24 03 000	Nut , self-locking	
	- 47	95 13 06 000	Screw	
	- 48	95 13 06 000	Screw	
	- 49	11 11 50 000	Washers, spherical.....	
	- 50	42 26 11 010	Bush, travel stop, nose L/G.....	
	- 51	95 61 02 000	Washer	
	- 52	95 63 06 000	Lock washer.....	
	- 53	95 61 06 000	Washer	
	- 54	95 24 07 000	Nut , self-locking	
	- 55	95 61 03 000	Washer	
	- 56	95 13 07 000	Screw	
	- 57	11 11 50 000	Washer	

(?) New bush bearing, equipped with a Quad Ring seal (from mid-1999, SN 1900 and on)
Interchangeable with part 42 20 32 010 bush bearing